



855-411-4321  
www.ClearStreamRecycling.com  
sales@cs-rec.com

## Lid Instructions

1. After securing the bag to the frame, immediately add the lid to the frame.



2. Attaching the lid will prevent the bag from filling up with wind.



3. There are four pairs of clips molded into the lid which snap on to the frames.



4. Center the lid on the frame, grasp the lid and the baglock on one side with both hands, and squeeze until you hear the lid lock into place. (You can also squeeze it one corner at a time.) Repeat on opposite side.

